



XC-G Series

Technical Manual (USA Version)

[*CLICK HERE FOR CONTENTS*](#)



| | | |
|---|---------------------------|-----------------|
| Power Supply | 220 volt | 110 volt |
| Motor Model | XL-G554-20Y | XL-G554-10Y |
| Control Box Model | XC-GMFY-2005 | XC-GMFY-1005 |
| Motor/Control Box Kit | XLG-554-20Y-KIT | XLG-554-10Y-KIT |
| Synchronizer (required for after market) | XC-KE-01P | |
| Rated Output | 550 Watt---3/4 Horsepower | |
| Rated Speed | 3600 rpm | |
| Speed Control Range | 70 rpm ~ 8999 rpm | |
| Note: 750 watt 1 horsepower model is also available in 220 volt only | | |

Options

| | |
|---|---------------------------------------|
| Pattern Selector | XC-G-500Y |
| Backtack On/Off toggle switches | AA-G003-925 |
| Ergo Pedal (3 separate pedals) | 1SP6A4 |
| Extension cord for ergo pedal (36 inches) | K14M71426631 |
| Electric Foot Lift | AA-EF4 |
| Air Foot Lift | AA-G200-PFL-15 |
| High Walk Kit for LU2-4710/4730 | AA-G004-600 (used with air foot lift) |